

Timeless *Designs*®

AREA RUGS

CECILIA COLLECTION

RUG CARE

Vacuum you rug regularly with a brushless nozzle. Keep in mind that the rug's edges, corners, and fringes are sensitive areas. We do not recommend using a vacuum with rotating brushes.

Clean spills immediately by using a white cloth and cold water to spot clean the affected area. Do not rub. Work towards the center of the spill.

For stubborn stains, please contact a professional rug cleaner.

For better comfort and increased safety, we recommend using a slip protection. The anti-slip underlay both protects the floor, holds the carpet in place, and provides a better walking comfort.

Rotate the rug once in a while to avoid wear or color fading caused by direct sunlight.

This rug is suitable for floors with subfloor heating systems.

Rug pad recommended.

CARE AND CLEAN:

Machine wash gentle or delicate. Use cold/cool water only. Use gentle soap. Do not use fabric softener. Do not use bleach. Tumble dry delicate low heat. Do not dry clean. Do not iron. Machine washable. Max 30°C/80°F. Check the washing machine for maximum wet weight capacity.